



Back Cover Removal

This guide will teach you how to remove the back cover of the Dell Inspiron 11-3162.

Written By: Dominic DeLong



INTRODUCTION


This will show you how to remove the back cover of the Dell Inspiron 11-3162. This is the starting point of all our guides here, and is necessary to reach the components of your laptop.



TOOLS:

- [Tweezers](#) (1)
 - [Heavy-Duty Spudger](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Back Cover Removal



- Remove the screw cover by using tweezers.

Step 2






- Using the phillips screw head (PH00), unscrew the 9 6.8mm philip screws.

Step 3



- Use the regular black nylon spudger tool to pry around the base edges of the back cover and remove it.

Step 4



- Gently pull upwards on the latch with tweezers
- When you've flipped the latch open, pull the ribbon cable outwards to disconnect the back cover from the motherboard.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-12-05 01:33:50 PM.